

Error Code	UIDAI Description	Description	Reason	Level	Remark
100	Invalid PidOptions input. XML should strictly adhere to spec.	Invalid PidOption input. XML should strictly adhere to spec.	Invalid setting from app		Invalid setting from app
110	Invalid value for fType	Invalid value of fType	should be 0 for FMR and 1 for FIR		Invalid setting from app
120	Invalid value for fCount	Invalid value of fCount	should be 1 to 10		Invalid setting from app
130	Invalid value for iType	Not applicable			
140	Invalid value for iCount	Invalid value of iCount	should be 0		Invalid setting from app
150	Invalid value for pidVer	Invalid value of pidVer	must be 2.0		Invalid setting from app
160	Invalid value for timeout	Invalid value of timeout	< 120 sec and > 1 sec		Invalid setting from app
170	Invalid value for posh	Invalid value of posh	Invalid setting from app		Invalid setting from app
180	Face matching is not supported	Face matching is not supported	should be 0 only		Invalid setting from app
190	Invalid value for format	Invalid value for format	0 for XML, 1 for Protobuff		Invalid setting from app
200	Invalid Demo structure	Invalid Demo structure	Invalid setting from app		Invalid setting from app
210	Protobuf format not supported	Not applicable, as Protobuff supported			
220	Not listed	Invalid value of env	S, PP or P		Invalid setting from app
700	Capture timed out	Capture timed out			User action required
710	Being used by another application	Being used by another application			
720	Device not ready	Not Connected with FM220	PI connect device		
730	Capture Failed	Capture stopped or Aborted / Device disconnected	User aborted capture or disconnected device		PI ensure proper USB connction if not aborted by user
740	Device needs to be re-initialized	Not applicable, as re-init is automatic			
760	RD Service does not support Iris	RD Service does not support Iris	Invalid setting from app		Invalid setting from app
900	Not listed	This FingerPrint scanner is only to be used with specific application	This is locked device and can only be used by the valid application		
999	Internal error	Not Connected with internet,Please connect with internet!!	Not able to connect to management server ACPL.IN.NET	Highest /Lowest	If device is not registred or certificat expired, it can not be used. Otherwise this is not a problem.
999	Internal error	Permission denied / Usb permission not granted	User has not granted permission	Law	User action required, user must allow permission, when asked for.
999	Internal error	Requested for Device Registration!, Please try after some time!!	Connectivity to Management server timed out, pl try again	Highest /Lowest	If device is not registred or certificat expired, it can not be used. Otherwise this is not a problem.
999	Internal error	Your device is not registered, pls register first!!	User action required, connect to internet and click register button.	High	User action
999	Internal error	Try after some time. Downloading UIDAI Certificate!!	PI wait to sync all required data	Law	Occurs only on first start of system and only if the internet is not available.
999	Internal error	Please set Automatic time or sync time correctly	Time setting of Tablet/mobile is not in sync and time of device has more than 10 min diff with server.	High	Capture will not be done till time is in sync or auto mode.
999	Internal error	Device connect failed. Try Again	PI check USB connection	High	PI check USB connection
999	Internal error	Can not connect to server.	PI ensure connectivity to management server	Highest /Lowest	If device is not registred or certificat expired, it can not be used. Otherwise this is not a problem.
999	Internal error	Please Check Staging/PreProd/Production Certificate, Your certificate is Invalid!!	PI ensure connectivity to management server	High	If connectivity to management server is available, this will resolve itself.
999	Internal error	Mobile / Tablet is not trusted	Android device is not passing mandatory safetyntest	High	PI update all google services and try. If this test is not passed, as per UIDAI, this tablet/Mobile can not be used in AADHAR eco system.

999	Internal error	Error occurred on starting of RD Service	Android device compatibility or other OS related problem	High	Need to contact our support team, we shall analyse the problem and provide resolution, if possible.
999	Internal error	Usb Manager not configured.	Android device compatibility or other OS related problem	High	Need to contact our support team, we shall analyse the problem and provide resolution, if possible.
999	Internal error	USB Interface failed	Android device compatibility or other OS related problem	High	Need to contact our support team, we shall analyse the problem and provide resolution, if possible.
999	Internal error	Usb Device connection not completed.	Android device compatibility or other OS related problem	High	Need to contact our support team, we shall analyse the problem and provide resolution, if possible.
999	Internal error	Error while getting device info XML	Android device compatibility or other OS related problem	High	Need to contact our support team, we shall analyse the problem and provide resolution, if possible.