

Radium Box

Step by Step SecuGen Hamster Pro 20 Drivers Installation (Complete Guide)

**For easy RD installation & accessible for common people.



How To Download SecuGen Hamster Pro 20 Drivers Installation?

What is SecuGen Hamster Pro 20?

SecuGen Hamster Pro 20 fingerprint scanner is STQC certified fingerprint scanner that uses FIPS 201 (PIV) and Mobile ID FAP 20 technologies. Featuring a comfortable, ergonomic design, Hamster Pro is built with the industry's most rugged and advanced optical sensor using patented SEIR fingerprint biometric technology.

Featuring a low-profile and IP65 Certified dust- and water-resistant design, the Hamster Pro 20 is built with the industry's most rugged and advanced optical sensor using patented and patent-pending fingerprint technology.

Requisites for SecuGen Hamster Pro 20 Drivers :

- Required OS
 - \circ Windows 8
 - o Windows 8.1
 - Windows 10
- 32 bit and 64 bit both supports with custom business applications
- Administrator login over computer/laptop
- High speed internet connection
- Antivirus should be disable
- Time zone of computer/ laptop is (UTC+05:30) Chennai, Kolkata, Mumbai, New Delhi

RD service renewal is compulsory before following the below steps , so kindly apply by using below link:

https://www.radiumbox.com/rd-service/online-register-biometric-device



Steps for Downloading SecuGen Hamster Pro 20 Drivers Installation:

<u>Step 1</u>: RD Service setup for SecuGen Hamster Pro 20 is available on our official website. So, to download SecuGen Hamster Pro 20 Driver installation, visit the following link:

https://www.radiumbox.com/



<u>Step 2</u>: After visiting our official website, click on the Download option that appears at the top of the home page. In the Download page, click on the Download Driver option available under Secugen RD Service.

https://www.radiumbox.com/rd-service-downloads.php



<u>Step 3</u>: After selecting the Download Driver option, you will be redirected to a new page where you need to click on the "Secugen Hpro20 Driver Download for Secugen Hpro20 - Windows" RD Service Download for PC Windows 10" based on the requirements of your system.

When you are finished, close your browser and open This PC from your desktop. From This PC, select Local Disk, then Users, followed by Your System Name, and move to the Download section. There you can find SGIRD_HU20_..... DRIVER

Double-click on the folder to extract the files, followed by selecting the Install option.

97100	Ø X 🗦 🚖 🖻 🛄 🖵 🗏 📁 🕀
Image:	X ^ 0
Image: Second	Jacet.un Select none Imert selection Select
← → ✓ ↑ Inis PC → Local Disk (C:) → Users → box → Downloads →	✓ Ŏ Search Downloads
MIS100/2 Name Date modified Type Size Photos Voday (6)	
This PC Solipetry Solipetry 24,721 This PC Solipetry Solipetry 24,721 Solipetry Solipetry 24,721 This PC Solipetry Solipetry Solipetry 3,702 Solipetry 3,702	KB KB
Destop Decuments Decuments	KB KB
Music V Last week (1 Fite folder Fite folder V Earlier Sum with Microsoft Defender Fite folder	
Witeos Control of a log of	KB
A rev Volume (k) Vast Month Government (k) Vast Month Government (k) Vast Month Government (k) Vast Month Vast Month Compressed (bips 9.381 Application 43,672 Send to	KB KB
163 items : 1 item selected 3.61 MB Cut Copy	تع <u>عن</u>
Create shortout Delete Rename	Activate Windows Go to Settings-Ki-activate Windows
Properties	Go to Settings to activate



<u>Step 4</u>: Press yes to continue installation.

Image: Corp path Brace Corp path Brace Corp path Brace Corp path Cipboard Image: Corp path Brace	File Home Share View Ap	Manage SGIRD_HU20(X)_110 plication Tools	52				- 0	~
	Pin to Quick access Copy Paste Shortcut	Move Copy Delete Rename	New item * Casy access * Properties New	Select all Select none Invert selection Select				
MIS100/2 Name Date modified Type Size Photos Biological Biological Biological Biological Imis PC Biological Biological Biological Biological Dological Dological Biological Biological Biological Biological Dological Dological Biological Biological Biological Biological Control Disk Continue? Control Disk Continue? Click Moxic Biological Execution Biological No Click Mission Biological Filts will install Securgen HU2000RD Service for Windows. Do pour with to continue? Click Were Volume (D) New Volume (D) New Volume (E) Execution Click	← → < ↑ → This PC > Downloa	ds > SGIRD_HU20(X)_11052	item Open	Sterr	v õ	Search SGIRD_HU20(X)_11052		
	MIS100/2 Name Photos Telegram Deskto Desktop Downloads Music Videos Local Disk (C) New Yolume (D) New Yolume (D)	^ Date 2000_11052 28-07	modified Type Si >2022 16:57 Application	e 3,729 KB 9 Serrice for Windows. Do 14 Yes No	• Click			
		Sho	w in folder					Ī
Show in folder						Activate Windows Go to Settinactivative Go to Settin	Windo	iw

<u>Step 5</u>: Fill the required information:

	~s	- +
I Image SGIRD_HU Manage SGIRD_HU	000_11052	×
Pinto Quick Copy Pate Pinto Quick Copy Pate Cipboard Cipboard	Ame I Rev Item - New Cost Properties Cost Properties (Cost Properties (CostProperties (Cos	
 Mis100/2 Mis100/2 Photos Telegram Dekto State Dektop 30 Objects Documents Documents Music Pictures Vianos Local Disk (C) New Volume (D) New Volume (D) New Volume (D) New Volume (E) 	Setup - SecuGen HU300/RD Service for Windows - × User Information Rease enter your information. User Name: Granization: Transform Transform Transform Transform Transform Transform	▼ δ Search SGRD_HU2000_11052
1 item 1 item selected 3.64 MB		
	Show in folder	Activate Windows ^{Go to Settil} Activৰ্শ্বশৈ [®] Windows Go to Settings to activate W

<u>Step 6</u> : Click next to continue, if you want to select different location select browse:

radium

I I Manage SGIRD_HU File Home Share View Application Tools	2000,11052	- □ × ^ 🕑
	Image: Several severa	
← → ↑ → This PC → Downloads → SGIRD_HU20(0_11052 MIS100/2 ↑ Name Photos Telegram Deskto	Setup - SecuGen HU2000/RD Service for Windows Select Destination Location Where should SecuGen HU2000/RD Service for Windows be installed?	X)_11052
This PC Dobjects Dobjects Documents Documents Documents Documents Pictures Victures Local Disk (C.) New Volume (D: New Volume	To continue, dak Hext. If you would like to select a different folder, dak Browse. C:Phogram Files (JuB)[SecuGen/RDService Browse At least 7.3 MB of fine disk space is required. kelect.org/limitstation.com At least 7.3 MB of fine disk space is required.	
1 item 1 item selected 3.64 MB	Show in folder	
	Activate W Go to Settings Downloads - Google Chrome Go	indows ইঔইইিউ₩িপিটিউws to Settings to activate V

Step 7: Wait for finishing the installation

I Image SGIRD_HU20 File Home Share View Application Tools	00,11052	- □ ×
Pin to Quick Copy Parte Parte Parte Shortcut	Image: Second	
This PC > Dewnloads > SGIRD_HU2000_11052 MIS10002 Photos Photos Telegram Destao This PC > Dewnloads > SGIRD_HU2000_11052 Photos Devnloads Doubjects Doubjects	Setup - Securiden HU2000RD Service for Windows Archaileg Installing Proceed with while Setup installs SecurGen HU2000RD Service for Windows en Printhing installation Printhing installation Canced	
	Show in folder	
		Activate Windows Go to Settinet Vindows

<u>Step 8</u>: Next Step is to install SGI_BWPI_S_32BIT, extract the files to get the application.

radium

↓ 2 ↓ File Home Share	E View Compress	Extract Downloads red Folder Tools		-	
An to Quick Copy Parts Copy Clipboard	Cut Copy path Paste shortcut To	Cogy Delete Rename Tolder	ritem *		
1 🛧 🕹 > This	PC > Local Disk (Ci) >	+ Users + box + Downloads		🐱 💍 🔎 Search Downloads	
MIS100V2	Name - Today (7)	Date modified	Type Size		î
This PC To blacks Desistop Desistop Desistop Downloads Music Felores Udeos Local Disk (C) New Volume (D) New Volume (D)	Security Secured Security Security Security Security Security Security Security	Verticality (2) 20 of star Hole Verticality (2) 100 star Hole Open in new kindow Open in new kindow Share with Skype Estrect All. Pois Sant Ø Scan with Microsoft Defender Ø Share Open with Give access to Restore previous versions	Compression (topp		
Network ¥ 164 items 1 item selected	WindowsRDServ 1.36 MB	Send to Cut Copy	Compressed (opp., 9,381 KB		
		Create shortcut Delete Rename		Activate Windows	
		Properties		Go to Setti Activate Win	10ws



✓ Ø . Search SOL BWAPLS, Win 32bit, 1.0.0.34	Select all Select none	Properties	New item •	💼 🔽 🖃	V	
✓ Ŏ Search SGL_BWAPL_S_Win_32bit_1.0.0.34		+ 🕑 History	New folder	Copy to	Copy path Paste shortcut to	uick Copy Paste
Search SGI_BWAPI_S_Win_32bit_1.0.0.34	Select	Open	New	Organize		Clipboard
			ility dender > ins >	Open Pana as daministratory Toubleshoot compatibility Toubleshoot compatibility Pin to Start Share with System Dial Share Give access to Pin to takkar Restore previous version Send to Cut Copy Create shortcut	1.38 MB	Telegram Deskto This PC 3 D Objects Desktop Documents Downloads Music Pictures Videos Local Disk (C:) New Volume (D: New Volume (D: Network V 1 item selected

В

<u>Step 9</u> : Click to accept the agreement and continue.

I Image Image SGL_BWAPI File Home Share View Application Tools	S_Win_32bit_1.0.0.34	×
Prito Quick Copy Patte Prito Quick Copy Patte Prito Quick Copy Patte Prito Quick Copy Patte Prito Quick Copy Prito Quick Prito	Annee Rev Item * Deter	
← → < ↑ 🦲 > This PC > Downloads > SGL_BWAPLS_Win_32bit	100.34	Search SGI_BWAPI_S_Win_32bit_1.0.0.34
MIS100V2 Name Photos JElegram Dexito	yg > secure a some river and over river is 12 of twoma	
30 Objects Desktop Document	agreement before continuing with the installation. SecruCen India Software License	
is uccuments ↓ Downloads Music ■ Pictures ₩ Videos	SecuGen Blometric Service. IMPORTANT - Read this License Agreement Carefully: This License Agreement (LA) is a legal agreement V	
Local Disk (C:)	f accept the agreement O I do not accept the agreement	
Network Item litem selected 1.38 MB	Next > Cancel	
	Show in folder	14 miles
Image Sol_BWAP_S File Home Share View Application Tools Image Sol_BWAP_S Image Sol_BWAP_S </th <th>Win_32bit, 1.0.034</th> <th> × ^0</th>	Win_32bit, 1.0.034	× ^0
← → × ↑ → This PC > Downloads > SGL BWAPLS Win 32bit 1	0.034	O Search SGI BWAPI S Win 32hit 1.0.034
Mistov Name ^ Photos j# SGLBWAPL5_Win_32bit_1.0.0.34 Telegram Deskto	User Information Image: Control of the second sec	
This PC 3 3D Objects Desktop Control Contro Control Control Control Control Control	User Name:	
is Doucoments ↓ Downloads ↓ Music is Pictures if Videos ↓ Local Disk (C.)		
New Volume (D: New Volume (E:) Network	<back next=""> Cancel</back>	
1 item 1 item selected 1.38 MB		
	Show in folder	
		Activate Windows ^{Go to Setti} 계산대성관람 Windows Go to Settings to activate W

radium

The Theme Share View Application roots		×
🥜 🖹 📋 🔏 Cut	🖹 🗙 📑 📜 🌇 New Item * 💭 🗊 Open * 🏪 Select all	
Pin to Quick Copy Paste	y Delete Rename New Properties Pittary Properties Pittary	
Clipboard O	Drganize New Open Select	
← → · ↑ 📴 > This PC > Downloads > SGI_BWAP	PLS_Win_32bit_10.034 V O O Search SGLBWAPLS	Win_32bit_1.0.0.34
MIS100V2 ^ Name ^	Ready to Install	
Photos	.0.0.34 Setup is now ready to begin installing SecuGen Biometric Web API over HTTPS (32 bit Windows) on your computer.	
	Click Install to continue with the installation, or click Back if you want to review or	
3D Objects	change any settings.	
Desktop	box	
Documents Documents Downloads	Destination location: C: Iprogram Files (x86)\SecuGen\\$gBloSrv	
) Music		
Pictures		
Videos	v	
New Volume (D:	< <u>></u>	
New Volume (E:)	< Back Install Cancel	
Network Y		
	Show in folder	
	Activate Wi	
	Go to Setting	Hvate Windows
		to Settings to activate V
Extract	Downloads	- • ×
Extract Extract Extract Extract Compressed Folder Compressed Compres Compres Compres Compre	Downloads Tools	- • × ^ 0
I III IIIIIIIIIIIIIIIIIIIIIIIIIIIIIII	Downloads Tools X Image: The Weak Item * Image: The Wittem *	× ^ (2)
File Home Share View Compressed Folder T File Home Share View Compressed Folder T File File File Gop path File Rates Paste Paste shortcut Sover Compressed Folder T	Downloads Tools Tools Pointe Remane Properties Proper	- • × ^ •
Pile Home Share View Compressed Folder T Pile Home Share View Compressed Folder T Pile Pile Compressed Folder T Pile Pile Pile Pile Pile Cipboard Pile Pile Pile View Pile Pile Pile	Downloads Teols Deixer Ramane Server Bray access Deixer Ramane Server Bray access Toder Teols	× ^ •
Ite Ite Share View Compressed Folder T Image: Share View Compressed Folder T Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share Image: Share	Downloads Tools To	× ^ 0
Image: Product set of the set of t	Downloads Tools To	×
Image: Product to the second seco	Tools Downloads Tools Image: Select all image: Select allot image: Select all i	×
Clipboard Clipboard More Cray Clipboard Clipboard More Cray Clipboard Clipboard	Tools Downloads Tools Image: Select all properties of the pro	
Compressed Folder T	Tools Downloads Tools Image: Select all properties of the pro	×
Corpressed Folder T Ide Hone Share View Compressed Folder Name Compressed Folder Name Today (9) SecuenceAsseque Today (9) SecuenceAsseque Folder SoreD_H0200(1102) SoreD_H0200(1102) Compressed Compressed Folder Name Name Today (9) SecuenceAsseque Name N	Tools Tools Tools Tools Detert Rename Tools Detert Rename Tools Tools Tools Select a Destination and Extract Files File will be extracted to this folder: C\U25 Show extracted files when complete	
Plet Mone Share View Compressed Folder Compressed Folder Compressed Folder Compressed Folder Compressed Folder Compressed Folder Plate SolgeApp P	Tools Tools Tools Describeds Detert Rename Hevy Failer Properties Mistory <	×
Pite Hone Share View Compressed Folder T Pite Hone Share View Compressed Folder T Pite Coult Compressed Folder T Pite Coult Compressed Folder T Pite Coult Compressed Folder T Pite Solution Pite Coult Compressed Folder T Pite Solution Pite Coult Compressed Folder T Pite Solution Pite Coult Compressed Folder T Pite Compressed Folder T Pite Coult Co	Tools Tools Downloads Deters Rename New tem Properties Estract Compressed (Zepped) Folders Select a Destination and Extract Files Select a Destination and Extract Files City Extracted files when complete er 21 Show estracted files when complete	
I Detact Interpretation Interpretation		
Clebeard		
Compressed Polder T Compressed Polder Compressed Compress Comprestate Compressed Compressed C	Tools	
Image: Provide and the second seco	Tool Tool	
Image: Provide and Provided And Provide	Tool Tool	
Image:	Tool Tool	
Intervention I	Control of the set of	
Cipbead Soare Vew Compressed Polder T Compressed Polder T	Control of the set of	
Carlow Compressed Polder T Carlow Compressed Carlow Compres	Tools To	
Image: Share View Compressed Polder T Price Quick Ceep Path Compressed Polder T Path Shore Path Shore Path Shore Cipboard Path Shore Path Shore Path Shore Cipboard Path Shore Path Shore Path Shore MSS100/2 Path Shore Path Shore Path Shore MSS100/2 Photos Securent Sages/DriverInstalle Securent Sages/DriverInstalle Downloads Maxic Securent Sages/DriverInstalle Securent Sages/DriverInstalle Downloads Maxic Securent Sages/DriverInstalle Securent Sages/DriverInstalle Downloads Maxic Securent Sages/DriverInstalle Securent Sages/DriverInstalle Pictures Videos Securent Sages/DriverInstalle Securent Sages/DriverInstalle Videos Securent Sages/DriverInstalle	Tool Tool Points Rename Ren	×

<u>Step 10</u>: Now open the universal legacy to install over the system.



Step 11: Click to agree the license terms & conditions:

Manage SecuCentes	acyOriverinstaller,23	×
A Cut ta Cuick. Capy Paula Dipboard Cupboard Dipboar	Anne Carport Contraction Anne Contractio	
This PC -> Downloads -> SecuGenLegacyDriverInst	aller_21 v	6 .P Search SecuGenLegacyDrivenInstaller_21
	SecuGen Universal Legacy Install SECUGEN SOFTWARE END USER LICENSE AGREEMENT OF USE THE ENCLOSED SOFTWARE DOCUMENTATION (AS DEFINED AS INSTALL SCRIPTS AND ONLINE OR ELECTRONIC DOCUMENTATION ASSOCIATED WITH	
	Show in folder	Activate Windows

Step 12: Installation of secugen hrpo20 rd is successfully done

In to Quick Copy Pasts	Cut Copy path Paste shortcut	Nove Copy Delate Ry to Organize	name New Toider	Properties Open	Select all Select none Invert selection Select		
	PC > Downloads Name Biometric_De M SpDnSetupUi 2gdx_v504	SerufienLegaryDriverin ^	Installation Suc	hpe See ey hutati Situp en Universal I cccessfully Comp	× egacy Install oleted	~ 0	
Network ¥ Jitems 1 item selected 21	4.548		Show in folder				Activate Windows Go to Settings Have wath Minderey

Now all the software for rd installation are successfully installed over the system, you can restart the services & use in your application

Share View	Application Tools	negecjonicinosito_cr					
Services					- 0	×	
File Action View	Help						
Services (Local)	Services (Local)		- A				✓ Ŏ ,○ Search SecuGenLegacyDriverInstaller_21
	SecuGen RD Service	Name	Description	Status	Startup Type	Log ^	1
	Stop the service	Secure RD Service		Running	Automatic	Loci	
	Restart the service	PrecisionRDService		Running	Automatic	Loci	
		A PrecisionManagementClient		Running	Automatic	Loci	1
		RecisionBiometricService		Running	Automatic	Loci	
		Service Morpho RD Service		Running	Automatic	Loci	
		Microsoft Office Groove Au			Manual	Loci	
		Google Chrome Elevation 5		Running	Automatic	Loci	1
		AtherosSvc		Running	Automatic	Loci	
		McpManagementService	<failed r<="" td="" to=""><td></td><td>Manual</td><td>Loci</td><td>1</td></failed>		Manual	Loci	1
		Display Enhancement Service	A service fo	Running	Manual (Trig	Loci	
		Sensor Service	A service fo		Manual (Trig	Loci	
		Windows Installer	Activates an	Running	Manual (Ing	Loci	1
		OpenSSH Authentication A	Agent to ho	Kunning	Disabled	Loci	
		CevicesFlow_a92e5	Allows Con		Manual	Loci	
		ConsentUX_a92e5	Allows Con		Manual	Loci	
		Windows Error Reporting Se	Allows error		Manual (Trig	Loci	
		Smart Card Removal Policy	Allows the r		Manual	Loci Y	
		<	Parent's the shi		manda	>	
1	Extended Standard						
							Activate Windows
							Go to SettingEtiveItetWindows
							Contraction of the second

В

Services (Local)	Services (Local)	1.2					28		
MIS1 Phot Phot Teles Dock Dock Dock Dock Dock Photu Photu Vides Nev Nev Nev Nev	SecuGen RD Service	Name	Description	Status	Startup Type	Log ^	~ 0	2	search seculenLegacyUnivernistalier_21
		SecuGen RD Service	Running Automatic	Automatic	Loc				
	Slog the service Restart the service	SynTPEnh Caller	Start	Running	Automatic	Loci			
		Recision RDServ	Stop	Running	Automatic	Loci			
		🔍 Precision Manag	Pause	Running Running Running	Automatic	Loci Loci			
		PrecisionBiomet	Resume		Automatic				
		A Morpho RD Serv	Restart		Automatic Manual Manual Automatic Automatic	Loci			
		Standard Microsoft Office				Loci			
		Google Chrome	All Tasks >	Running A Running A Running M Running M Running M		Loci			
		Scanner Scanner S	Refresh Properties Help			Loci			
		AtherosSvc				Loci			
		G) McpManageme			Manual	Loci			
		Display Enhance			Manual (Ing	Loci			
		Sensor service	ine Sec. Activates en		Manual (Trig	Loci			
		Windows Installer	Addr. modi		Manual Manual	Loci			
		OnenSSH Authentic	ation A Agent to bo		Disabled	Loci			
		DevicesFlow a92e5	Allows Con		Manual	Loci			
		ConsentUX a92e5	Allows Con		Manual	Loci			
		Windows Error Repo	orting Se Allows error		Manual (Trig	Loci			
		Remote Desktop Ser	Remote Desktop Services U Allows the r		Manual	Loci			
		Smart Card Remova	Smart Card Removal Policy Allows the s		Manual	Loci Y			
		<				>			
	Extended Standard								
Stop and Start service	SecuGen RD Service on Local Comp	outer							

🕹 i 🖸 📴 🖛 i		Extract Download:	5					- 0	×
File Home Share	e View Con	pressed Folder Tools							~ ?
Pin to Quick Copy Paste	Cut Copy path	Move Copy to to to	New item •	Properties	Select all Select none Invert selection				
Clipboard	_	Organize	New	Open	Select				
← → ∽ ↑ ↓ → Π	his PC > Local Disk	(C:) > Users > box > Downloads	5 >			ŭ v	, Search Downloads		
MIS100V2 ^	Name	Dat	e modified Ty	pe Si:	e				^
Photos	V Today (6)								
Telegram Deskto	SecuGenLeg	acyDriverInstaller_21 26-0	09-2022 16:56 Co	ompressed (zipp	24,721 KB				
💻 This PC	SGI_BWAPI_	5_Win_32bit_1.0.0.34 26-0	09-2022 16:55 Co	ompressed (zipp	1,396 KB				
3D Objects	SGIRD_HU20	Open	Co	ompressed (zipp	3,702 KB				
Desktop	chanda chro	Open in new window	JP.	G File	167 KB				
Documents	Telegram De	Share with Skype	Fi	le folder	332 KB				
🖶 Downloads	✓ Last week (1)	Extract All							
Music	Office 2007	Pin to Start	FI	le folder					
Pictures	V Farlier this n	Scan with Microsoft Defender.		ie rolaei					
Videos		Onen with	5 M	icrosoft Edge P	30 K.B.				
New Volume (D:	V Last month (Give access to		lefosore edge +	35 KD				
New Volume (E:)	WindowsRD	Restore previous versions		opporessed (zipp	0 381 KB				
Network	Q L385_x64_25	Send to	> Ap	pplication	45,672 KB				~
163 items 1 item selecte	ed 3.61 MB	Cut							
		Сору							
		Create shortcut							
		Delete					Activate Window	/5	
		Rename					Go to Settings id acti	ate Window	SME
		Properties					Go to Set	tings to ac	tivate \



For any technical assistance/enquiry please call us-+91 84343 84343

**Disclaimer: The brand names & information used in this pdf is for general demonstration and informational purpose only . The graphical representation is for user understanding easy demonstration.